

Assembly & Installation Instructions

- 1. Lay out Panels as pictured.
 - Console Panel has 3 channels.
 - Side Panels are longer.
 - Back Panel has one channel.

Insert 8 x T-Connectors into all T-Slots in the BlackPak panels.



2. Connect Back Panel into Bottom Panel. Secure using self-tapping screws through bottom panel into T-Connectors.



3. Connect Side Panels (1), then connect Console Panel (2). Secure using self-tapping screws through bottom panel into T-Connectors.



4. Install Console Slides on Top Panel. Align Slides with pre-drilled holes. Position slides so the "ledge" is to the outside. Secure with self-tapping screws, ensuring screws go through counter-sunk side. Insert Back of Console onto Slides. It is a snug fit and may take a bit of pressure to slide onto the Console panels.



- 6. Install Tracks on desire end of top panel using pre-drilled holes and machine screws with locknuts Tracks.
- (For 4300 Elite Upgrade Kit)

 Insert RotoGrip Paddle
 Holder and BullWinkle into

 Track.
- 8. Insert in the Bow Crate Space on Pursuit and secure with Mighty Bolts & Mighty Knobs.
- 9. Install bungee cord for use as door latch.